

INSTALLATION AND OPERATION MANUAL

EZ-MCP1

Microphone Compressor

Model numbers:
EZ-MCP1 includes power supply with North American plug
EZ-MCP1X includes worldwide power supply (specify plug)

Visit the RDL website for hundreds of professional A/V products made in the USA by RDL.

www.rdl.net.com

Decades of Performance, Quality and Value


RDL • 659 6th Street • Prescott, AZ • USA 86301 • Sales: 800-281-2683 • 928-443-9391
Tech Support: 800-933-1780 • 928-778-3554 • RDL Europe Sales & Support: (31) 20-6238-983

EZ-MCP1

Microphone Compressor

- Produces Consistent Levels from Any Microphone
- Installs Between Microphone and Mixer/Amplifier
- Improves Intelligibility with Fast Automatic Level Control
- Controls Overloads that Cause Distortion and Clipping
- Front-Panel Set-Up Trimmer with LED Indicator
- Automatic Phantom Voltage Switching with LED
- XLR Input and Output

TYPICAL APPLICATION



Insert Power Plug

Rotate 1/4-turn
clockwise to lock

Rotate 1/4-turn
counter-clockwise
to unlock

Screw
directly to flat
surface without
installing rubber feet.

Peel backing and stick the 4 rubber
feet to chassis in recesses provided.

Recess

Bottom View
of chassis

SELECTED MOUNTING ACCESSORIES Complete accessory listing available at: rdlez.com

EZ-RA6

Rack Adapter for 6 Increments of 1/6 Rack Width

EZ-CC6

Component Chassis for 6 Increments of 1/6 Rack Width

EZ-SMB1

Surface Mount Bezel for 1/6 Rack Width Products

EZ-DC1

Desktop Chassis 1/6 Rack Width

EZ-UCB2

Under-Counter Brackets 1/6 or 1/3 Rack Width

EZ-SD1

Storage Drawer 1/6 Rack Width
Use In Place of Filler Panel
Holds Adapters and Cables
Mounts in EZ-CC6 and EZ-RA6

TYPICAL PERFORMANCE